





SERVO-DRIVE

Austausch der Antriebseinheit | Replacement of drive unit | Échange de l'unité motrice |
Sostituzione dell'unità motrice | Sustitución del equipo de accionamiento | Заміна привода



Vor jedem Eingriff den Netzstecker ziehen | Disconnect the mains plug before change |
Débrancher la prise d'alimentation avant toute intervention | Prima di ogni intervento staccare la spina |
Antes de cada intervención tiran el cable de red | Перед будь-яким втручанням витягніть кабель живлення

Demontage | Removal | Démontage | Smontaggio | Desmontaje | Демонтаж



Montage | Assembly | Montage | Montaggio | Montaje | Монтаж

